

StoneDeks™ System INSTALLATION METHODS



Installation of SilcaGrate™ as a patio overlay provided pitch and level are correct on existing surface

Install sleepers using vinyl or plastic lumber installed on a 16" OC pattern in the direction of the pitch of the patio allows for $\frac{3}{4}$ of an inch for drainage underneath.



For roof top overlay with limited mechanicals or no obstructions .

the SilcaGrate™ can be supported with plastic or vinyl sleepers . allowing $\frac{3}{4}$ of an inch for drainage beneath , install in the direction of scuppers or drains and hold back $\frac{1}{4}$ of an inch from the edge of the side of you roof .

If there are large mechanical obstructions . conduit or mechanical access points then the need to use pedestals or a framing system or a combination of both will be needed.

